

3eBin™ - Scoop bin assembly instructions

COMPONENT OVERVIEW:



Components:

- | | |
|-----------------|-----------------------------|
| 1. Catch tray | 7. Label holder |
| 2. Body | 8. Catch tray holder |
| 3. Scoop | 9. Front |
| 4. Scoop holder | 10. Top lid |
| 5. Consumer lid | 11. Internal signage holder |
| 6. Cord | 12. Divider |

3eBin™ - Scoop bin assembly instructions

PLEASE FOLLOW THE BELOW INSTRUCTIONS FOR ASSEMBLY OF YOUR SCOOP BIN:



1. Insert **scoop holder** into dedicated slits on the inside of bin front.



2. Snap **bin front** into slits on both sides of bin body.



3. Attach bottom part of **internal signage holder** by inserting it behind the two dedicated stoppers on the inside of bin front.



4. Press the top part of **internal signage holder** toward front until it locks.



5. Insert **consumer lid label holder** into its dedicated space. Listen for click signaling the holder has been installed properly.



6. Bend the right part of the bin body slightly outwards and plug in **consumer lid**. Do this for both sides.

3eBin™ - Scoop bin assembly instructions



7. Attach top lid to bin.



8. Insert **cord** into its dedicated hole in scoop. Insert cord into its dedicated hole on the side of the bin body.



9. *(If your bin doesn't have a divider, please skip this step.)* Install **divider** by plugging it into its dedicated hole and slit in the back of bin body and in the slit in the front part of the bin body.



10. *(If your bin doesn't have a catch tray, please skip this step.)* Insert **catch tray holder** from the back. Ensure it locks into its dedicated holes.



11. *(If your bin doesn't have a catch tray, please skip this step.)* Insert **catch tray** completely. Ensure catch tray sits between the catch tray holder and the bin body.



12. Insert **scoop** into scoop holder. Your scoop bin is now fully assembled.