

# 3eBin™ - Scoop bin **disassembly** instructions

## COMPONENT OVERVIEW:




### Components:


1. Catch tray	7. Label holder
2. Body	8. Catch tray holder
3. Scoop	9. Front
4. Scoop holder	10. Top lid
5. Consumer lid	11. Internal signage holder
6. Cord	12. Divider

## 3eBin™ - Scoop bin disassembly instructions


PLEASE FOLLOW THE BELOW INSTRUCTIONS FOR ASSEMBLY OF YOUR SCOOP BIN:



1. Remove **top lid**.



2. Remove **scoop** from scoop holder.



3. Lift the consumer lid and bend it outwards until the **label holder** falls off.



4. Bend the right part of the bin body slightly outwards and **unplug consumer lid** from it. Do this for both sides.



5. Hold bin in place using your one arm. At the same time, pull at the corner of **bin front** so it comes off. Do this for both sides.



6. Pull off **internal signage holder** from bin front.

## 3eBin™ - Scoop bin disassembly instructions

---



7. Pull off **scoop holder** from front.



8. (If your bin doesn't have a divider, please skip this step.) Remove **divider** by unplugging it from its dedicated hole and slit in the back and front of bin body.




9 a. Using a tool such as a tong, grip the one end of the **cord** and push it out of bin body.



9 b. Press the other end of **cord** tightly together using your fingers. Push cord out of scoop.



10. (If your bin doesn't have a catch tray, please skip this step.) Pull out **catch tray** completely.



11. (If your bin doesn't have a catch tray, please skip this step.) Pull out **catch tray holder** completely. Your scoop bin is now fully disassembled.