



AVALIABLE EXTERNAL LENGTH OF YOUR TRAY:






PLEASE FOLLOW THE INSTRUCTIONS BELOW:




1. Remove the clip at the rear of the tray by bending it a few times. This clip will be used in step 3.



2. At desired breaking point, bend the tray back and forth until it breaks.



3. Attach the clip (from step 1) to the rear of the U-tray.



4. Press until you hear a click. Make sure the clip is attached correctly to the tray.



5. Done!

HL DISPLAY AB

Cylindervägen 18, Box 1118 131 26 Nacka Strand - Sweden Tel +46 8 683 73 00 info@hl-display.com

www.hl-display.com

