


Facer™ & Facer™ XL


Mounting instruction

Facer™ & Facer™ XL

- 1** Thoroughly clean and dry shelf.




- 2** Confirm required position of front rail, then remove the protection film from the rail, place the rail at the front of the shelf and press firmly.



Facer™ & Facer™ XL


3

Adjust the width to fit your products.



4


Place the frame behind the front riser. Ensure the Facer™ front sits in the locking channel for the best fit.



Facer™ & Facer™ XL


5

Repeat the mounting procedure until completion.




Facer™ XL with eXtender

- 1 Choose Portrait or Landscape position based on your product.
Align the arrows and press down to lock top and base plates together.



- 2 Lock the eXtender plate to the Facer™ XL frame.
The eXtender should be attached to the rear of the Facer™ XL frame with the HL logo facing towards the front.



Facer™ XL with eXtender

- 3** Simply place onto your shelf with the eXtender plate facing towards the customer.

