





FreshGrid table

Mounting instruction

front frame




2 Attach the side to the front frame using two bolts




© HL Display 2(12)

Attach the other side to the front frame using two bolts




4 Attach the back frame to both sides using four bolts




© HL Display 3(12)

Attach the support bar to the bottom frame using two bolts




Attach two lockable wheels at the front and two standard wheels at the back




© HL Display 4(12)

Slide the front panel into place on the guide rail




8 Hang the front panel on the guide rail




© HL Display 5(12)

Remove one row of tiles for easy access to attach the side panel




1 Use self tapping screws to attach the mounting panel




© HL Display 6(12)

fit the cladding to the mounting panel




12 Fix the side panel with six self tapping screws




 \bigcirc HL Display 7(12)

13 Put the tiles back in place




14 Fix each tile into position with four screws




© HL Display 8(12)

15 Attach the corner covers




16 Secure the corner covers in place with two screws




© HL Display 9(12)

FreshGrid table – attach the table top to the bottom frame


17 Slide the table top on to the bottom frame hinges






© HL Display 10(12)

FreshGrid table – attach the table top to the bottom frame





© HL Display 11(12)

