


3eBin™ - Scoop bin accessories

SHUTTER ASSEMBLY:



1. Remove the **top lid**, consumer lid and bin front according to the instructions for your bin.



2. Insert the **shutter** into the dedicated slots on the inside of the bin body. If your bin has a divider, you will have two smaller shutters instead of one larger one. Re-assemble the top lid, consumer lid and bin front according to the instructions for your bin.

SHUTTER DISASSEMBLY:



1. Remove the **top lid**, consumer lid and bin front according to the instructions for your bin.



2. Remove the shutter from the dedicated slots on the inside of the bin body. Disassemble the rest of your bin according to the instructions for your bin.

REPLACE SCOOP BY TONG:



1. Remove the cord from the scoop according to the instructions for your bin.



2. Squeeze the end of the cord into the dedicated hole in the tong. Place the tong in the scoop holder.