





Facer™

Mounting instruction

Clean the shelf




Remove the protection film from the rail, place the rail at the front of the shelf and press firmly




© HL Display 2(5)

Adjust the width to fit your products




4 Place the frame behind the front riser



© HL Display 3(5)

5 Repeat the mounting procedure until completion



© HL Display 4(5)

