



Multivo™ Max
Mounting instruction
- Installation on wire shelf

Multivo™ Max - Mounting instructions on 3-4 mm wire shelf

WHAT YOU NEED:

MU-WRAIL (MU-clip included) or MU-MAX rail
MU-MAX pusher tray

TAPE RECOMMENDATION:

For freezer: Use TTFC
For cooler: Use TTMR, TTP & TP



Press the MU-clip, item reference: 732757, on the wire shelf until you hear a click. Use at least three clips per shelf, mount these at approximately 15-20 cm interval.



Remove the protective plastic from the rail.



Place the MU-rail with the thinner edge outwards.



Press down firmly.



Place the pusher tray on the rail.



Multivo™ Max is now ready-installed on wire shelf.



For the bottom shelf, a rail of magnetic tape is used.

Multivo™ Max - Mounting instructions on 3 mm wire shelf

WHAT YOU NEED:

MU-MAX clip
MU-MAX pusher tray



Scan to watch
installation video!



MU-MAX clip, item: 554257. Front clip side as shown in the picture.



Open the metal dividers, attach the MU-MAX clip to the plastic front making sure that the frontal part is in right position (pic 1).



Apply force and make sure the back side of the MU-MAX clip attach correctly to the plastic front. The MU-MAX clip should not move.



Mount the MU-MAX tray in the wire shelf and adjust the tray dividers according to package width.



Make sure the MU-MAX clip is properly attached to the shelf.



Multivo™ Max is now ready-installed on wire shelf.